



Switch Settings for Price Options

→Manufacturer's recommended settings

	Setti	ings of 6	-Toggle	Switch o	on Millip	ede TM P	5)	
8	7	6	5	4	3	2	1	Option
On On On Off Off Off	On Off Off On On Off Off	On Off On Off On Off				Off	Off	Demonstration Mode For every 3 coins inserted, logic adds 1 more coin For every 5 coins inserted, logic adds 1 more coin For every 4 coins inserted, logic adds 2 more coins For every 4 coins inserted, logic adds 1 more coin For every 2 coins inserted, logic adds 1 more coin No Bonus Coins ◀
			Off On					Left coin mechanism x 1 ◀ Left coin mechanism x 2
				Off Off On On	Off On Off On			Right coin mechanism x 1 ◀ Right coin mechanism x 4 Right coin mechanism x 5 Right coin mechanism x 6
						On On Off Off	On Off On Off	2 coins for 1 credit 1 coin for 1 credit ◀ 1 coin for 2 credits Free Play

Switch Settings for Play Options

	Settings of 8-Toggle Switch on Millipede TM PCB (at D5)											
8	7	6	5	4	3	2	1	Option				
Off On	Off On			• •				Select Mode ◀ No Select Mode Easy spider ◀ Hard spider				
		Off Off On On	Off On Off On					Bonus life every 12,000 points Bonus life every 15,000 points ◀ Bonus life every 20,000 points No bonus life				
				Off Off On On	Off On Off On			2 lives per game 3 lives per game 4 lives per game 5 lives per game	OPTION SWITCH			
						Off On	Off On	Easy beetle Hard beetle Easy millipede head Hard millipede head	LOCATIONS ON THE MILLIPEDETM PCB			

Switch Settings for Special Options

8	Settings of 8-Toggle Switch on Millipede TM PCB (at P8)												
	7	6	5	4	3	2	1	Option					
On Off	On Off							1 coin counter ◀ 2 coin counters 1 credit minimum ◀ 2 credit minimum					
								Select Mode Starting Score					
		Not used	Not used	On On Off Off	On Off On Off			0 points 0 and bonus life level 0, bonus life level, and 2 x bonus life level 0, bonus life level, and 2 x bonus life level, and 3 x bonus life level					
						On On	On Off	English ं⊸l German					
						Off Off	On Off	French Spanish					

Self-Test Procedure

ST-217 1st printing

This game will test itself and provide data to show that the game's circuitry and controls are operating properly. The data is provided on the video display and speaker. No additional equipment is necessary.

We suggest you perform the self-test procedure when you first set up the game, any time you collect

money from the game, when you change game options, or when you suspect game failure.

To perform the self-test, set the self-test switch to the *on* position. To end the Self-Test Mode, set the self-test switch to the *off* position.

Test Passes

- 1. Set the self-test switch to on. All credits will be cancelled.
- Press each control panel and auxiliary coin switches. Insert coins into both coin slots (coins will not be counted on the coin counter).
- 3. Roll the Midi Trak-Ball. TM

Instruction

- 4. Press the 1-player start switch at least 64 times.
- 5. Press the 1-player start switch eight times.
- Observe 16 blocks of color in the character set on right side of the screen.
- Press and hold the 2-player start switch and press the FIRE switch.
- Roll the Midi Trak-BallTM and press 2-player start switch 16 times.
- To erase the EAROM (erases the high-score table and game statistics), simultaneously press both start switches and EIRE
- 10. To end the test, set the self-test switch to off.

The self-test display appears. RAMs and ROMs are tested. The start LEDs remain on during the test. If the screen is different from the self-test display, or if there are sounds, refer to Chapter 2, Self-Test Procedure.

When you press a switch, the appropriate 1 changes to 0 on the screen and you will hear a high tone. If the test fails refer to Chapter 2.

A motion object picture moves around on the screen in directions corresponding to the Midi Trak-Ball, IM If the test fails, refer to Chapter 2.

Each time you press the 1-player start switch, the motion object changes shape. If test fails refer to Chapter 2.

You will hear a high tone each time you press the 1-player start switch. If the test fails refer to Chapter 2.

Each of the 16 block should contain a different color, If test fails refer to Chapter 2.

Playfield objects change color with each press of the FIRE switch. If test fails refer to Chapter 2.

Each time you roll the Midi Trak BallTM and press 2-player start switch a motion object is moved from the diagonal group of objects in the center of the screen and placed in a new location on the screen. Test for 16 motion objects in this manner. If test fails refer to Chapter 2.

The message EA FF appears in the upper left corner of the screen. The message remains on the self-test screen until the next game is completed.

