

Game PCB removal

1. Remove the 56-pin edge connector from the right side of the PCB on the Shield Cover.
2. Pull out 6 Fasteners located on perimeter of the Shield Cover.
3. Remove the Game PCB from the Shield Cage by carefully sliding it straight out of the wooden PCB retainer.
4. Pull out 2 Fasteners at the center of the Shield Cover. The Game PCB can now be separated from the Shield Cover.

WARNING

In order to maintain protection against Radio Frequency Interference radiated from this equipment, after servicing the Game PCB, be sure to close the Shield Cover completely by use of the Fasteners located on the perimeter of the Shield Cover.